A1 TOWING Pro-Tek Detachable Towbars

Fitting Instructions

LR706FS
LR706DS

Including Stratum Powder Coat Finish

LANDROVER FREELANDER 2

e11*94/20*7173*02

	Components			Bolt Kit W 545		
	Code	**Quantity**	**Description**	**Code**	**Quantity**	**Description**
Mainframe	CB	1	Crossbar	WB	2	10mm Large Round Washers
	AN	1	Angle	SW	1	10mm Small Round Washers
	AB	1	Angle Bracket	WA	2	14mm Large Round Washers
	LS	1	Left Strap	H	2	14x90 Bolts & Grip Washers
				E	2	10x40 Bolts, Nuts & Grip Washers
				I	1	10x40 Bolts & Grip Washers
				B	1	12x35 Bolts, Nuts & Grip Washers
				C	1	12x35 Bolts & Grip Washers
Flange Neck	F	1	Flange Neck	G	2	16x50 Set Screws, Nuts & Grip Washers
	AV123	1	Towball Cover	A	2	12x100 Bolts Nuts & Grip Washers
Detachable Neck Pro-Tek Detachable Towbars	D	1	Detachable Towbar Neck & Housing	Z	4	12x25 Set Screws & Sprung Washers
	AV124	1	Towball Cap			
	AM173	1	Electrical Socket Mounting Plate			
	AN208	1	Dust Cover			
	AN3nn	2	Keys			
	AN209	1	Operating Manual			

1. Remove the left hand rear reflector from the rear bumper and drill 2 x 20mm diameter holes at 120mm centres as shown in diagram. Remove lower fixings from bumper.
2. Loosely attach angle **AN** to left hand chassis using bolt **H** with washer **WA.**
3. Insert mainframe **CB** between the rear towing eye and angle **AN** and loosely attach to angle **AN** using fasteners **B** and **C**.
4. Loosely attach mainframe **CB** to the original hole in towing eye using bolt **I** with washers **WB** and **SW**. Remove the rear most bolt attaching towing eye to vehicle and loosely attach angle bracket **AB** to vehicle towing using original bolt.
5. Loosely attach angle bracket **AB** to mainframe **CB** using fasteners **E** with washers **WB**.
6. Remove the two original nuts attached to the rear panel using the two holes drilled through the bumper.
7. Loosely attach left strap **LS** to the rear panel using the original nuts. Loosely attach left strap **LS** to angle **AN** using fasteners **H** with washers **WA.**
8. Attach flange neck **F** or detachable neck **D** to mainframe **CB** using fasteners **A** or **Z.**
9. Tighten and check all fasteners and replace reflector and bumper fixings.

PLEASE REFER TO YOUR VEHICLE HANDBOOK FOR THE MAXIMUM TOWING WEIGHT

All A1 Stratum towbars are finished with our unique powder coat.

A1 Towing Limited, Parkway Link, Kettlebridge Road, Sheffield, S9 3AJ
T: 0800 404 7070 F: 0845 30 10 476 E: technicalsupport@a1tow.com
www.a1tow.com

A1 TOWING Pro-Tek Detachable Towbars